## **QUALITY CONTROL CHECKSHEET**

for TPO MEMBRANES

## **ABS UNCOUPLING SYSTEM**

| Site Name                          |   |   |   |     |    |          |  |
|------------------------------------|---|---|---|-----|----|----------|--|
| Site Address                       |   |   |   |     |    |          |  |
| Date                               |   |   | QC process  | YES | NO | Comments |  |
|                                    |   | uroTUF TPO substrate is clean, free of dust, dirt and any minants.  |   |     |    |          |  |
|                                    | The ABS PSA liquid is stirred before using a within "used by" date.   |   |   |     |    |          |  |
|                                    | The ABS PSA adhesive is applied on a clean, dry substrate at 15m² per litre and is fully tacked off before the ABS UNCOUPLING SYSTEM mat is installed.  |   |   |     |    |          |  |
|                                    | pre cut   | The ABS UNCOUPLING mat (component Schluter Ditra 25) is<br>ore cut and ready for installation, allowing for 6mm clearance<br>from all abutments.  |   |     |    |          |  |
|                                    | from all  | The ABS UNCOUPLING mat is installed with 6mm clearance from all abutments – smoothed into the ABS PSA with hand pressure using a float to ensure a continuous bond.                               |   |     |    |          |  |
|                                    | the duro  | Seal the perimeter edge with TPO (JM) sealant directly onto the duroTUF TPO membrane also adhering onto the ABS UNCOUPLING mat to create an abutment seal. Leave any drip edge free from sealant. |   |     |    |          |  |
|                                    | UNCOU   | PLING MAT joond. Install  | Joint Flashing Tape to all ABS joints, centralised and pressure rolled to single piece expansion joints at 3m <sup>2</sup> in |     |    |          |  |
|                                    | Flashing  | er lay the TPO abutment sealant with ABS self-stick Joint shing Tape 10mm onto the duroTUF TPO membrane ove PTPO sealant and onto the ABS UNCOUPLING mat.   |   |     |    |          |  |
|                                    | Using Construction Chemicals Monoflex rubber based tile adhesive, install the selected tiles, keeping a continuous clearance from the exposed duroTUF TPO membrane usi artists brush or similar.  Clean out any tile adhesive ooze for the sealant. |   |   |     |    |          |  |
|                                    | voids) under the tile   |   | e is cleaned out of the 6mm abutment at   |     |    |          |  |
|                                    | HG MS grey sealant.<br>Mask off the tiles and the dure  |   | nd the duroTUF TPO upstand<br>I higher than the tile finished surface to  |     |    |          |  |
|                                    | On the sealant completion, carefully remove the masking tape to leave a straight finish sealant line on the duroTUF TPO upstand and against tiled finish.   |   |   |     |    |          |  |
| Install the Construct epoxy grout. |   |   | cion Chemicals Epegrout water washable  |     |    |          |  |
| Installing Applicator - Name       |   | Name  |   |     |    |          |  |
| Installing Applicator Signature    |   |   |   |     |    | Date     |  |
| Head Contractor - Name             |   |   |   |     |    |          |  |
| Installing Applicator Signature    |   |   |   |     |    | Date     |  |

