

CONCRETE SUBSTRATE READINESS CHECKSHEET

for Roofing & Decking Membrane Installation

duroTUF TPO



Project/Site Name	
Site Address	
Applicator	
Main Contractor	

QC process	✓	Tick when completed
Concrete cured for a minimum 28 days and thoroughly dry (RH 75%).	<input type="checkbox"/>	
Any curing compounds removed.	<input type="checkbox"/>	
Surface smooth and clean to specified falls, otherwise to NZBC.	<input type="checkbox"/>	
Cavities and cracks filled with Gripset DM mortar and flushed off, all Latescence removed, all ponding removed.	<input type="checkbox"/>	
Allproof SUREFLOW dropper outlets installed just under flush with concrete surface.	<input type="checkbox"/>	
Allproof SUREFLOW dropper overflows installed just under flush with concrete surface.	<input type="checkbox"/>	
Type 316 Stainless Steel scupper outlets installed just under flush with concrete surface.	<input type="checkbox"/>	
Allproof overflow sumps installed just under flush with concrete surface.	<input type="checkbox"/>	
If terminating into a chase, pre-form the chase and ensure that it is straight and 20mm deep.	<input type="checkbox"/>	
All internal angles set at 90 degrees, no fillets required.	<input type="checkbox"/>	
Plinths formed for any exterior ventilation, fixtures or similar.	<input type="checkbox"/>	
Venting is required on all concrete substrates. Install 35mm wide grid tapes at 600mm centres.	<input type="checkbox"/>	

WHEN THE SUBSTRATE IS READY, COMPLETE THIS FORM AND EMAIL TO THE WATERPROOFING SUBCONTRACTOR

Notes			
Name			
Signature		Date	